




**FIG. 1**



**FIG. 2A**




**FIG. 2B**



**FIG. 3**


**FIG. 4**




**FIG. 5**

70


Num Lock	/	*	-
7 Home	8 ↑	9 PgUp	+
4 ←	5	6 →	
1 End	2 ↓	3 PgDn	Enter
0 Insert		.	
		Del	




**FIG. 6A**




**FIG. 6B**




**FIG. 7A**



**FIG. 7B**



**FIG. 8**



**FIG. 9**







FIG. 10

**FIG. 11**












**FIG. 13**



**FIG. 14**



**FIG. 15**



**FIG. 16**





FIG. 18B is a schematic diagram of a user interface for a system. The interface includes a central display area 292 and several peripheral buttons. The buttons are labeled 27a, 27b, 27c, 27d, 27e, and 27f. The central display area 292 contains the text 'HEALTHY LIVING AND FOOD' and a list of choices: 1. FRUITS, 2. VEGGIES, 3. MEATS, and 4. GRAINS. The display area also features icons of a sun, two trees, and a house. The buttons are arranged around the display area: 27a is at the top left, 27b is at the top center, 27c is at the top right, 27d is at the bottom left, 27e is at the bottom center, and 27f is at the bottom right.





FIG. 18B





**FIG. 19**





FIG. 20



**FIG. 21**

FIG. 22 is a block diagram of a menu editing screen 330. The screen 330 includes a menu edit button 332, a menu number display 334, and a menu list 336. The menu list 336 includes a menu heading 340, a menu timer 342, a menu picture 344, a menu pre-text 346, a menu post-text 348, a menu video 350, a menu sound file 352, a menu database 354, and a menu next item 356.




FIG. 22

